

# NISSAN ALMERA TINO DASH TO 2003



USE C7 CABLE, WE ONLY NEED TO TAKE OFF BACK PART OF DASH, LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US. **NEVER** TOUCH NAILS, IT IS VERY DANGEROUS. MEMORY INSIDE THIS KIND OF CARS IS A 93C56 (S221).

