

# NISSAN CABSTAR FROM 2008



USE CABLE C7, OPEN BACK PLASTIC COVER FROM DASH, THEN LOCATES POINTS SHOWN ON BELOW PHOTO, AND THEN SOLDER CABLE LEADS CONCORDANCE WITH ITS NUMBER OR COLOUR:

