

# NISSAN PATHFINDER FROM 2007



USE CABLE C12, REMOVE BACK PLASTIC COVER FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTOS:

