

NISSAN PICK-UP



USE CABLE C4, REMOVE FRONT PLASTIC COVER, TAKE OFF SPEEDOMETER, ONLY FIXING WITH 4 SCREWS. THEN LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

