

NISSAN TERRANO2 TO 2001



USE CABLE C12, REMOVE DASH FROM CAR, REMOVE BACK PLASTIC COVER FROM DASH, YOU JUST PULL IT OUT. SOLDER POWER LEADS AND COLOUR LEADS LIKE WE CAN SEE ON NEXT PHOTOS ACCORDING TO THEIR COLOURS:

