

OPEL SIGNUM 2003



USE CABLE C4, OPEN ALL DASH, PLEASE MAKE IT VERY CAREFULLY, SPECIALLY TO TAKE OFF SCREEN, THEN LOCATE EPROM MEMORY, USUALLY WE DON'T NEED TO DESOLDER IT, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

