

PEUGEOT 206 BSI FROM 2002



USE CABLE C4, REMOVE BACK PLASTIC COVER FROM BSI, THEN LOCATE EEPROM AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

