

# PEUGEOT 307 BSI FROM 2006



USE CABLE C4, REMOVE BACK PLASTIC COVER FROM BSI, THEN LOCATE EEPROM AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

