

# PEUGEOT 406 DASH JAEGER TO 2000



USE CABLE C11, REMOVE DASH FROM CAR, OPEN BACK COVER OF IT, WITH SOME TORX SCREWS. SOLDER POWER LEADS AND COLOUR LEADS LIKE WE CAN SEE ON NEXT PHOTOS ACCORDING TO COLOURS: **(REMEMBER TO LIFT UP 2 PINS)**

