

# RENAULT SAFRANE C46



USE C7 CABLE, WE ONLY NEED TO TAKE OFF BACK PART OF DASH, LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US. MEMORY INSIDE THESE KIND OF CARS ARE A 93C46.

