

# ROLLS ROYCE PHANTOM CAS



## TWO WAYS TO MODIFY THIS MODULE:

1. **TAKE OFF** KEY FROM IGNITION. WITHOUT DASH INTO CAR, TURN LIGHTS ON AND RADIO OR OTHER ELECTRIC EQUIPMENT, THEN CONNECT ENIGMA + ADAPTER A3 + OBD2 OR C40 IN DASH PLUG AND PROGRAM IT.
2. USE CABLE **C45 + A6 ADAPTER**. REMOVE MODULE FROM CAR CAREFULLY, OPEN IT, LOCATE POINTS IN THE BOARD AND SOLDER CABLE LEADS AS SHOWS TO US BELOW PHOTO:

