

SKODA FABIA FROM 2007



USE CABLE C4, REMOVE DASH FROM CAR AND OPEN IT COMPLETELY. SEPARATE BOTH BOARDS FROM DASH. CHECK IF MICRO IN DASH IS MICRONAS 3272, THEN LOCATE EPROM 24C32 AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

