

SMART ROADSTER SAM



USE CABLE C12, OPEN ALL CAREFULLY, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO PIN AS SHOWN OF BELOW PHOTO:

