

# SUZUKI BURGMAN



USE C7 CABLE, WE ONLY NEED TO REMOVE OUTSIDE PLASTIC COVERS FROM DASH, LOCATE POINTS ON THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

