

# SUZUKI DRZ-400



USE CABLE C4, OPEN ALL DASH, COMPLETELY AND CAREFULLY, THEN LOCATE EPROM, AND CLIP IT CHECKING **PIN 1** AS SHOWN TO US PHOTO BELOW:

