

SUZUKI SV650-1000 TO 2002



USE CABLE C7, REMOVE BACK PLASTIC COVER FROM DASH, THEN LOCATE EEPROM POINTS, AND SOLDER CABLE LEADS CHECKING NUMBERS AND COLOURS AS SHOWN INTO BELOW PHOTO:

