

SUZUKI JIMMY 908



Use C12 CABLE, OPEN DASH AND REMOVE SPEEDOMETER ONLY:

NOW ONLY SOLDER CABLE LEADS ACCORDING TO POINTS AS SHOWN ON BELOW PHOTO:

