

SUZUKI JIMMY C56



USE CABLE C4, OPEN DASH COMPLETELY, CAREFULLY, WHEN WE HAVE MAIN BOARD IN OUR HANDS WE MUST LOCATE EPROM, AND CLIP IT CHECKING **PIN1** AS SHOWN ON BELOW PHOTO:

