

# TOYOTA AVALON



Use **CABLE C5**, OPEN CAREFULLY ALL DASH, THEN LOCATE EPROM **93C46** MEMORY, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

