

TOYOTA CAMRY



USE CABLE C5, REMOVE BACK PLASTIC COVER FROM DASH CAREFULLY, AND THEN LOCATE EEPROM 93C46 AND CLIP IT CHECKING PIN 1 AS WE CAN SEE ON THE PHOTO BELOW:

