

# TOYOTA LANDCRUISER 2006



Use C7 cable, ON THE BACK OF THE DASH, LOCATE POINTS ON THE MAIN BOARD, LIKE IN PHOTO BELOW, AND SOLDER CABLE LEADS AS IT SHOWS TO US:

