Toyota MR2 From 2000

Use cable C7, remove dash from car, it can take you some time... Remove back cover from dash, and then locate points in the main board like in photo below and solder cable leads as it shows to us: