

# VOLVO C70 HC08



USE C12 CABLE, REMOVE DASH FROM CAR, NEXT CAREFULLY OPEN DASH. AFTER OPEN IT, REMOVE METAL COVER OVER MOTOROLA MCU FROM INSIDE. NOW WE HAVE MAIN BOARD FREE, LOOK FOR U7 CHIP AND LIFT UP PIN NR7, THEN SOLDER WHITE AND GREEN CABLE AS ON PHOTO SHOWN BELOW:



