

# VOLVO S40-V40 2003-2005



USE C7 CABLE, WE MUST REMOVE OUT BACK PLASTIC COVER, LOCATE POINTS ON THE BACK SIDE FROM MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

