

VOLVO S80 FROM 2008



USE C12 CABLE, REMOVE DASH FROM CAR AND OPEN BACK COVER. LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

