

VW CONSTELLATION DASH



USE C4 CABLE, AFTER REMOVE DASH FROM CAR, TAKE OFF BACK PLASTIC COVER, WHEN WE HAVE MAIN BOARD IN FRONT, NOW WE CAN LOCATE EPROM LIKE IN PHOTO BELOW AND CLIP IT CHECKING **PIN 1** AS IT SHOWS TO US:

