

YAMAHA T-MAX FROM 2008



USE CABLE C4, REMOVE BACK PLASTIC COVER OF DASH, THEN LOCATE EPROM MEMORY AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

