

YAMAHA XV 1900



USE CABLE C7, REMOVE BACK PLASTIC COVER FROM DASH, AFTER LOCATE POINTS ON THE MAIN BOARD, SOLDER CABLE LEADS CONCORDANCE WITH ITS NUMBER-COLOUR AS PHOTO SHOWS TO US:

