# CITROEN C4 PICASSO DASH

USE CABLE **C4**, OPEN DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EPROM MEMORY **93C66**, USUALLY WE DON´T NEED TO DESOLDER IT, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

VERSION 1:

VERSION **2**:

PIN 1 ⟶