


HARLEY DAVIDSON 25010



USE CABLE C4, REMOVE BACK PLASTIC COVER CAREFULLY, AND THEN LOCATE EPROM MEMORY

25010, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

