

HONDA FIT 2004-2007



USE CABLE C4, OPEN ALL DASH, COMPLETELY AND CAREFULLY, THEN LOCATE EPROM NEAR THE SCREEN, BE CAREFULLY; SOMETIMES MUST BE CLEANED, AND CLIP IT CHECKING **PIN 1** AS SHOWN TO US PHOTO BELOW:

