

# LEXUS GS400



USE CABLE C4, OPEN BACK COVER FROM DASH, CAREFULLY, THEN LOCATE EPROM 93C46, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

