ENIGMA USER MANUAL

MERCEDES C - W203 DASH TO 2005

DASHBOARD PHOTO:

REQUIRED CABLE(s): C4







FOLLOW THIS INSTRUCTION STEP BY STEP:

- 1. Remove the dashboard and open it carefully.
- 2. Locate the EEPROM memory.
- 3. Look at PHOTO1 to find correct position of PIN1 or look at PHOTO2 to see how to connect C30 cable.
- 4. Connect the EEPROM memory using C4 cable.
- 5. Make sure that you connected the C4 clip correctly.
- 6. Press the READ EEP button and save EEPROM memory backup data.
- 7. Press the READ KM button and check if the value shown on the screen is correct.
- 8. Now you can use the CHANGE KM function.



PHOTO 1: Connect cable C4 to the EEPROM memory according to the picture above.



ENIGMA USER MANUAL

MERCEDES C - W203 DASH TO 2005



PHOTO 2: Connect cable C30 to the Plug shown on the photo above.

LEGAL DISCLAIMER:

DIAGCAR ELECTRONICS S.L. does not take any legal responsibility of illegal use of any information stored in this document. Copying, distributing or taking any action in reliance with the content of this information is strictly prohibited.

