

# CITROEN C1 DASH

## ENIGMA



USE CABLE C4, OPEN BACK COVER FROM DASH, THEN LOCATE EPROM MEMORY 93C56, USUALLY WE DON'T NEED TO DESOLDER IT, BUT CLEAN IT WILL BE NECESSARY AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

