

CITROEN C4 PICASSO DASH



USE CABLE C4, OPEN DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EPROM MEMORY 93C66, USUALLY WE DON'T NEED TO DESOLDER IT, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

