

CITROEN XSARA DASH FROM 2002



THESE DASHES HAS ONLY ONE PLUG ON THE BACK. USE CABLE C4, OPEN BACK PART OF DASH WITH SOME SCREWS, THEN, CAREFULLY, REMOVE NAILS, AND OPEN BOARD, BE MUCH PATIENT, SCREEN MUST BE CONNECTED TO BOARD. LOCATE 93C66 MEMORY, AND CLIP IT CHECKING **PIN 1** AS SHOWN IN PHOTO:

