

FIAT SCUDO DASH DIAG



USE SPECIFIC CABLE C20, REMOVE DASH FROM CAR, AND CONNECT PLUG TO DASH LIKE WE CAN SEE ON NEXT PHOTO AND RUN PROGRAM:

