


# LEXUS IS200-IS300

## ENIGMA



Use C4 CABLE, OPEN REAR PART OF DASH, THEN SOME SCREWS WILL BE APPEARS, NAILS AND YOU WILL HAVE FREE THE MAIN BOARD, THEN LOCATE EPROM MEMORY 93C46, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

**THIS IS NOT THE CORRECT ONE**



## ENIGMA

**POWER SUPPLY**

16 & 17	+12V
19	GND

**CLIP MEMORY 93C46**



## ENIGMA