


PEUGEOT 207 DASH



USE CABLE C4, OPEN DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EEPROM 93C66 MEMORY AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

