

PEUGEOT 307 DASH NEC 2002-2005



USE CABLE C13 ALWAYS CONNECTED TO A1 ADAPTER. OPEN ALL DASH, PLEASE MAKE IT CAREFULLY, ON MAIN BOARD SOLDER CABLE LEADS ACCORDING TO NUMBER AS SHOWN INTO PHOTOS:

