

ISUZU RODEO



USE CABLE C5, OPEN CAREFULLY ALL DASH, THEN LOCATE EPROM 93C46 MEMORY, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

