

MERCEDES BENZ C-W203 DASH FROM 2005



USE CABLE C4, OPEN ALL DASH, PLEASE MAKE IT VERY CAREFULLY, THEN LOCATE EPROM MEMORY, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

