

MB SPRINTER DASH FROM 2000



USE CABLE C4, OPEN BACK PART OF DASH, BE CAREFULL, THEN LOCATE EPROM 93C66, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

