

# Audi A8 2003-2009 dash pinouts

---

## Multi-pin connector, 32-pin, blue

1. Terminal 30
2. Terminal 30
3. Terminal 31
4. Terminal 31
5. Vehicle speed warning system wake-up wire
6. External buzzer
7. Brake pad
8. Oil level
9. Radio-controlled clock signal
10. Radio-controlled clock 5V
11. EPB 2 (el. parking and handbrake 2)
12. EPB 1 (el. parking and handbrake 1)
13. Not used
14. Brake fluid low
15. Oil pressure switch
16. Not used
17. Terminal 58s
18. Terminal 30
19. Terminal 31
20. Washer fluid low
21. Coolant level low
22. Fuel tank sender earth
23. Fuel gauge sender 4 -G393- (tubular sender, right-side)
24. Ambient temperature
25. Fuel gauge sender 3 -G237- (tubular sender, left-side)
26. Fuel gauge sender 2 -G169- (lever-type sender, right-side)
27. Fuel gauge sender -G- (lever-type sender, left-side)
28. Sender earth
29. Vehicle speed warning system CAN High
30. Vehicle speed warning system CAN Low
31. MMI CAN High
32. MMI CAN Low

