

MCU DEVICE DATUM

Oznaczenia modelu procesora po numerze maski :

A75H - MC68HC811A2

B19C - MC68HC811E2

B46E - MC68HC11A8

B60R - MC68HC11E9 ??

B65H - MC68HC11A8

B76T - MC68HC11A8 ??

B83T - MC68HC05B6

B84N - MC68HC11A8 ?? E9 ?? Woodstock SQR88 (ZC98378CFN BP5WD17)

B91T - MC68HC05B6 ??

B95T - MC68HC11A8

B96D - MC68HC11A8

C13W - MC68HC11L6 ??

C14H - MC68HC05B6

C27B - MC68HC11E9

C47M - XC68HC711E9

C83W - MC68HC11E9 ??

C85W - XC68HC711L6

D20J - MC68HC05B16

D28J - MC68HC705B16

D35E - MC68HC11E9 ??

D40J - MC68HC705B32

D40J - MC68HC705X32

D53J - MC68HC05X32

D54J - MC68HC05B16

D58J - MC68HC11PA8

D59J - MC68HC705B32

D59J - MC68HC705X32

D60J - MC68HC05B16 ??

D61N - XC68HC711KA4

D62J - MC68HC05X16

D64J - MC68HC(7)11P2

D67F - XC68HC711K4

D69J - MC68HC05X32

D82R - MC68HC11E9

D99H - MC68HC711P2

E20T - MC68HC705C4A

E22B - MC68HC11E20

E28B - MC68HC11E9

E53M - MC68HC711P2

E57S - MC68HC11KA4 ??

E59B - MC68HC11KA4 ??

E61W - MC68HC705F8

E74J - MC68HC11P2

E82K - MC68HC11E20

F11N - MC68HC11L6

F41E - MC68HC05L28 (podobný)

F49K - MC68HC705C8A

F52E - MC68HC11E32

F53E - MC68HC11KG4

F56K - MC68HC705B16

F62J - MC68HC05B16

F96J - MC68HC11E9 ??

F97J - MC68HC11E9 ??

F88B - MC68HC705X4

G10V - MC68HC11P2 ??

G28F - MC68HC05B16

G35N - MC68HC05B16

G41V - MC68HC705B32

G47V - MC68HC705X32

G59F - MC68HC711E20

G96A - MC68HC705B32