

BMW 1 SERIES E87 CAS2 TO 2006 V2

CAS 2 PHOTO:



REQUIRED CABLE(s): C40



FOLLOW THIS INSTRUCTION STEP BY STEP:

1. First disconnect the dash.
2. Connect cable C40 to dash plug in the car.
3. Make sure that the connection you made is secure and correct.
4. Choose the CAS2 DIAG CAN program and run it.
5. Press the READ KM button and check if the value shown on the screen is correct.
6. Now you can use the CHANGE KM function.

LEGAL DISCLAIMER:

DIAGCAR ELECTRONICS S.L. does not take any legal responsibility of illegal use of any information stored in this document. Copying, distributing or taking any action in reliance with the content of this information is strictly prohibited.

FOR MORE INFORMATION

Call **0034 983 359 787** or visit www.enigmatool.com

DIAGCAR ELECTRONICS S.L. Ebanistería 1A, 47610 Zaratán, Spain